



EUROMAT
CLEANING & MAINTENANCE INSTRUCTIONS

Cleaning: painted products require particular attention. Unlike fabrics or vinyls, paint is sensitive to abuse, will absorb stains and will discolor if badly handled. With proper techniques and normal precautions, material can be readily cleansed of soil and stains with little or no damage

Maintenance: normal maintenance requires a periodic cleaning with a vacuum or soft brush. Any remaining soil should be removed with a dry erase sponge

Stains: caution! Do not use any form of solvent, detergent or bleach. Do not use any form of dry cleaning solution or spot removers as they may destroy the gloss, cause delamination or change the color

- The primary consideration in stain removal is prompt attention
- Act quickly to minimize damage
- Determine the nature of the stain before attempting removal
 - Fluids:
 - Blot with clean tissue, sponge or cloth
 - Do not rub or press soil into the fabric
 - Semi Solid
 - Scrape off excess with knife or sponge
 - Blot with clean tissue or cloth
 - Confine the area by working from the edges toward the center
- Use only cold water or the finish may discolor and lose gloss
- If stain persists, add a very mild soap such as IVORY, LUX or BORATINE to cold, clean water and blot, sponge or brush with a soft brush

Caution! Always test your cleaning process in a discrete area before attempting stain removal